

# Pin holes treatment Procedure

## Method

### 1 Before pin holes treatment

Knead Repair Resin to a slightly stiff consistency.



### 2 Filling the repair material

Fill in the pin holes with Repair Resin, let it overhang and dry as it is.



### 3 Scraping

When Repair Resin is half dried, scrape off the overhanging bits.



### 4 Surface treatment

When it's completely dried, rub it with sandpaper to match the surroundings.



### 5 Finished look

It's all completed.



## Tools to prepare

- Trowel(1~2mm)
- Bowl
- Scraper
- Waterproof Sandpaper #600
- Small bucket
- Brush
- Gas torch

## Materials to prepare

- Repair Resin
- Water

## Notes

- All Repair Resin products are pre-mixed and only use water for kneading. Please note that the curing time and color may differ if any adhesives are mixed.
- Once it's mixed with water, please use it all. **Re-watering or kneading once curing has started** may cause cracks and poor adhesion.
- Because it's cement-based, it is subject to weathering and moisture absorption. Please store with care and use as soon as possible. (The 5kg inner bag is heat-sealed to improve shelf life. Please use the rubber band attached for sealing any leftover products.)
- When repairing, remove the excess unevenness of the surface beforehand with a hammer, chisel, scraper, etc., and clean it. If the mold releasing agent remains on the surface, it'll peel off easily. Use a brush to scrub the surface and moisten it with water for the best results.
- Please be careful when handling a scraper or a metal trowel, as they may cut your hand.
- **Please read the instructions and notes** of C Repair Lining and C Repair Color.
- After adding the Mixing Liquid into C Repair Color, please use it all within 24 hours.
- Cover and protect the area where you don't wish to spray paint beforehand.
- If it adheres to any unwanted area, wipe it off with a wet wiping cloth.
- Please make sure to mix C Repair Color thoroughly before use. If it's not fully mixed, it may cause unevenness.
- Spray C Repair Color **little at a time in thin layers**. If you spray too thickly at once, it may drop, and the finished look will not look as good. Please repeat the process of "Spray → Dry → Spray" until the surface is fully covered.
- When adding patterns, tap lightly and inconsistently according to the surrounding patterns.



コンクリートの補修屋さん  
**Concrete Repair**

WADA TRADING CO., LTD.

<https://con-rep.com> e-mail : [info@con-rep.com](mailto:info@con-rep.com)  
6-5-1, Akura-naka, Takarazuka-city, Hyogo, Japan